



Vista installation guide

Included in the set:

- 1 x filter housing**
- 2 x fittings (pre-installed)**
- 2 x hoses**
- 1 x wrench**
- 1 x wall bracket**
- 1 x filter cartridge**

1:

Insert the filter cartridge into the filter housing and then tighten the bottom and top together. Be sure that the cartridge is centered. If it is crooked, the top and bottom will be difficult to connect, and the cartridge will need to be adjusted. Use the included wrench to tighten everything completely.

2:

The filter housing can be mounted on the wall under the sink with the supplied wall bracket. If you choose to mount the filter, ensure that enough space is left below the filter to allow for future filter cartridge replacement. The filter housing can also stand under the sink without being permanently mounted.

3:

Installation:

Turn off the water supply to the cold outlet, either at the main valve or, if available, at a small valve under the sink.

Locate your cold water outlet and disconnect your cold water hose.

Attach the supplied hoses to each side of the filter housing. Pay attention to the arrows on top of the filter housing, which indicate the direction of the water flow.

The two supplied hoses are not identical—one fits your cold water outlet, and the other is used to connect the filter housing to the loose hose from your faucet.

Once both hoses are attached to the filter housing and tightened, you can connect the inlet hose to your cold water outlet. Then, attach the second hose from the filter housing

to the loose hose from your faucet, which you previously disconnected from the cold water outlet.

Carefully turn the water back on and check for any leaks. If there are any, you may need to tighten the connections where the leak occurs.

Let the water run for 5 minutes to flush out any excess carbon from the filter.